





Err018 Control power Undervoltage	Incorrect wiring or input power failure	1. Check input power or wiring 2. Replace the servo drive
Err019 Tripping	Incorrect wiring may make the control diverge and result in motor stall.	1. Check U/VW and encoder wiring. 2. Check the motor and drive. Replace it when necessary.
Err020 Overvoltage	1. Input power voltage exceeds 280VAC. 2. Regenerative resistor breakage or not matching. 3. Load inertia exceeds acceleration/deceleration time or replace more suitable drive/motor. 4. Drive broken.	1. Check input power voltage. 2. Check or replace regenerative resistor. 3. Increase acceleration/deceleration time or replace more suitable drive/motor. 4. Drive broken.
Err021 Undervoltage	1. Input power voltage drops. 2. Instantaneous power off. 3. P08.36 setting is too high. 4. Drive broken	1. Make sure input power is stable. 2. Reduce P08.36 value if input power is normal. (Memory is configurable by P07.19)
Err022 Current sampling fault	Drive internal current sampling fault	Replace servo drive.
Err023 AI sampling voltage too large	1. AI wiring wrong; 2. AI external input power voltage too high	Do correct AI wiring and set input power voltage within ±10V.
Err024 Overspeed	1. Speed instruction exceeds maximum speed setting value. 2. Wrong U/VW phase sequence. 3. Speed response over modulation. 4. Drive faulty	1. Lower speed instruction 2. Check U/VW phase sequence is correct. 3. Adjust speed loop gains to reduce overshoot. 4. Replace drive
Err025 Electrical angle identification failure	1. Load or inertia too large; 2. Wrong encoder cable wiring	1. Reduce load or increase control loop gain. 2. Replace encoder cable.
Err026 Load identification failure	1. Load or inertia too large. 2. Motor cannot run at specified curves; 3. Verification process aborted	1. Reduce load or increase control loop gain 2. Make sure verification process correct.
Err027 DI parameter setting fault	1. Different DOs are assigned with same function. 2. Physical DI and communication DI have error	Reassign DI functions
Err028 DO parameter setting fault	Different DOs are assigned with same function	Reassign DO functions
Err040 S-ON instruction invalid fault	Input S-ON signal after motor is energized by other auxiliary functions	Change incorrect operation.
Err042 Pulse division output overspeed	Pulse division output is over upper limit.	Adjust pulse division output settings.
Err043 Position deviation too large	1. Servo motor U/VW wiring is wrong; 2. Servo drive gain settings are too low; 3. Position instruction pulse frequency is too high. 4. Motor acceleration/deceleration is too large; 5. P00.19 setting is too low; 6. Brake release abnormal; 7. Brake release power and servo motor is locked by external forces, gravity etc.	1. Reconnect the cables 2. Increase servo gains 3. Reduce instruction frequency, acceleration or adjust gear ratio 4. Set up smoothing parameters. 5. Adjust the value of P00.19 6. Replace the drive 7. Check brake power and servo motor is not blocked.
Err044 Main circuit input phase loss	1. Input power cable bad contact. 2. Phase loss fault, i.e. during power on, one phase of R/S/T is too low	1. Check input power cables 2. Measure R/S/T phase-to-phase voltage to ensure 3 phases are balanced and input power is up standard.
Err045 Drive output phase loss	1. Motor U/VW bad contact. 2. Motor broken	1. Check U/VW wiring 2. Replace motor
Err046 Drive overload	1. Motor U/VW or encoder cable bad contact or loose 2. Motor blocked or brake not released 3. Wrong U/VW/encoder cable wiring for multiple drives/motors 4. Motor/drive too small for load phase loss or wrong phase sequence 6. Motor or drive broken	1. Check U/VW/encoder cable wiring 2. Check motor is not blocked and brake is released 3. Check there is no wrong U/VW/encoder cable wiring for multiple drives/motors 4. Increase acceleration/deceleration time or choose bigger drive/motor 5. Check U/VW wiring 6. Replace drive/motor
Err047 Motor overload	1. Motor U/VW or encoder cable bad contact or loose 2. Motor blocked or brake not released 3. Wrong U/VW/encoder cable wiring for multiple drives/motors 4. Motor/drive too small for load 5. Phase loss or wrong phase sequence 6. Motor or drive broken	1. Check U/VW/encoder cable wiring 2. Check motor is not blocked and brake is released 3. Check there is no wrong U/VW/encoder cable wiring for multiple drives/motors 4. Increase acceleration/deceleration time or choose bigger drive/motor 5. Check U/VW wiring 6. Replace drive/motor
Err048 Electronic gear setting fault	Electronic gear ratio exceeds setting range	Set correct electronic gear

Err049 Heat sink too hot	1. Fan broken 2. Ambient temperature is too high 3. Too many times of restarting power after overload 4. Inappropriate installation directions and spacing 5. Servo drive faulty 6. Motor or drive broken	1. Check fan. Replace fan or drive 2. Measure ambient temperature and improve cooling conditions for servo drive. 3. Check error records and see if there has been overload error. Restart after 30s. Increase acceleration/deceleration time. 4. Check installation directions according to specifications in this manual. 5. Servo drive faulty 6. Power off and wait for 5 minutes. If this error persists, replace drive.
Err050 Pulse input abnormal	1. Input pulse frequency is larger than maximum frequency setting 2. Input pulse is interfered.	1. Adjust P08.38 2. Check wiring grounding conditions. Use twisted pair shielded cable. Separate UVW cable from encoder cable. 1. Check external encoder wiring. Replace external encoder. 2. Check parameters of fully-closed loop deviation and protective function.
Err051 Fully-closed loop position deviation too large	1. External encoder abnormal. 2. Relative settings too conservative.	1. Check external encoder wiring. Replace external encoder. 2. Check parameters of fully-closed loop deviation and protective function.
Err054 User forced fault	User uses DI of function 32 FORCE_ERR to forcibly enter fault state.	Disconnect DI of function 32.
Err055 Absolute position resetting fault	Absolute encoder absolute position resetting fault	Contact HCFA.
Err056 Main circuit outage	Power outage or main circuit abnormal	Check if there is instantaneous power failure. Increase power voltage capacity.
Err060 First start after writing customized software	First start after writing customized software	Initialize the servo drive.
Err065 CAN bus OFF	CAN bus disconnection or Receive or send failure	Check the wiring
Err066 Abnormal NMT command	Receive NMT stop or reset command at servo-ON	NMT mode reset. Do not stop or reset CAN node at servo-ON.
Err067 CAN bus failure	CAN bus disconnection or Receive or send failure	Check the wiring
Err068 External overspeed (reserved)	1. Speed exceeds the max speed setting value 2. U/VW phase error 3. Speed response severely overshoot 4. Drive faulty	1. Reduce speed 2. Check U/VW phase sequence 3. Adjust speed loop gain 4. Replace servo drive
Err069 Excessive hybrid deviation	1. External encoder disconnection 2. External encoder breakage 3. Drive transmission failure	1. Check or replace external encoder or wiring 2. Check mechanical transmission
Err071 Node protection heartbeat overtime	Do not get any response when node protection and heartbeat monitoring reach the setting value	Check the nodes, NMT node reset
Err072 Synchronization failure	Failure between the CANOpen and host controller in IP mode	NMT mode reset or 6040 send failure reset command
Err073 CANOpen Trace buffer underflow	CANOpen. Synchronous clock loss more than 2 times in IP or CSP mode	Check any interference to the communication and operation of host controller. NMT mode reset or 6040 send failure reset command
Err074 CANOpen Trace buffer overflow	CANOpen Sync. Clock too fast or the actual clock frequency does not match the setting value of IP or CSP mode	Check any interference to the communication and operation of host controller. NMT mode reset or 6040 send failure reset command
Alarm code and name	Causes	What to do
AL080 Undervoltage warning	DC bus voltage is relatively low.	1. Check main circuit. 2. Adjust P08.36
AL081 Drive overload warning	Same as Err046	Same as Err046
AL082 Motor overload warning	Same as Err046	Same as Err046
AL083 Parameter modification needs restart	Modify parameters which needs restarting.	Restart power
AL084 Servo not ready	S-ON when servo is not ready.	S-ON after detecting S-RDY signal
AL085 EEPROM frequency writing warning	Operating EEPROM too frequent.	Reduce EEPROM using frequency. Use communication2 which do not save in EEPROM.
AL086 Positive over-travel warning	1. POT & NOT valid simultaneously 2. Servo over-travel in some direction, this alert will be removed automatically.	Trigger positive limit switch, check operation mode, move the servo towards negative direction. After leaving positive limit switch, this alert will be removed automatically.
AL087 Negative over-travel warning	Same as AL086	Trigger negative limit switch, check operation mode, move the servo towards positive direction. After leaving negative limit switch, this alert will be removed automatically.

AL088 Positive instruction overspeed	1. Electronic gear ratio too large 2. Pulse frequency too high	1. Reduce electronic gear ratio 2. Reduce pulse frequency
AL090 Absolute encoder angle initialization warning	Angle is over 7.2 degree.	Replace motor
AL093 Regenerative overload	1. Regenerative resistor wrong wiring or bad contact; 2. Internal resistor wiring breakage; 3. Resistor capacity insufficient; 4. Resistor resistance too large and causing long time braking; 5. Input voltage exceeds specifications 6. Resistor resistance, capacity or heating time constant parameters settings are wrong; 7. Drive faulty	1. Check resistor wiring 2. Check internal resistor wiring. 3. Increase resistor capacity 4. Reduce input voltage 5. Set correct parameters 6. Replace drive
AL094 Regenerative resistor too small	Regenerative resistor value is less than minimum value	1. Replace resistor 2. Check parameters P00.21-P00.24
AL095 Emergency stop	Emergency stop is triggered	This is a normal DI function (function 30)
AL096 Homing error	1. Homing time exceeds P08.95 2. P08.90 is set to 3, 4, or 5 and contacted limit switches 3. Contact limit switches twice when not using limit switches as origin points	1. Increase the value of P08.95; 2. Reduce homing speed P08.92, P08.93
AL097 Encoder battery undervoltage	Encoder battery voltage is lower than what's set in P08.48.	Replace battery.

### DIDO function code

Value	Sign	Name	DI function description	Remarks
1	S_ON	Servo enable	Invalid-Servo disabled Valid- Servo enabled	
2	ERR_RST	Error reset	Servo continues to work after some error reset. Valid when detecting edge change.	
3	GAIN_SEL	Gain switchover	Invalid-Speed loop is PI control. Valid-Speed loop is P control.	
4	CMD_SEL	Command switchover	Invalid- present command is A. Valid- present command is B	
5	PERR_CLR	Pulse deviation	Invalid-No action Valid-Clear pulse deviation	
6	MI_SEL1	Multi-stage selection 1		
7	MI_SEL2	Multi-stage selection 2		
8	MI_SEL3	Multi-stage selection 3		
9	MI_SEL4	Multi-stage selection 4		
10	MODE_SEL	Control mode switchover	Switchover of control modes(speed/m position, torque) when P00.01 is set to 3, 4 or 5.	
12	ZERO_SPD	Zero-speed clamp	Valid-Enable zero-speed clamp Invalid-Disable zero-speed clamp	
13	INHIBIT	Pulse input inhibition	Valid-Disable pulse input Invalid-Enable pulse input	
14	P_OT	Positive over-travel	Use with limit switches for over-travel protections. Valid-Positive over-travel, positive drive disabled Invalid-Normal range, positive drive enabled	
15	N_OT	Negative over-travel	Use with limit switches for over-travel protections. Valid-Negative over-travel, positive drive disabled Invalid-Normal range, positive drive enabled	
16	P_CL	External forward torque limit	Valid-External torque limit enabled Invalid-External torque limit disabled	
17	N_CL	External reverse torque limit	Valid-External torque limit enabled Invalid-External torque limit disabled	
18	P_JOG	Positive JOG	Valid-input instructions Invalid-Stop inputting instructions	
19	N_JOG	Negative JOG	Valid-Reverse input instructions Invalid-Stop inputting instructions	
20	GEAR_SEL1	Electronic gear selection 1	Valid- first electronic gear Invalid- first electronic gear	
21	GEAR_SEL2	Electronic gear selection 2	Valid- second electronic gear Invalid- second electronic gear	
22	POS_DIR	Position instruction negation	Valid-Not reverse; Invalid-Reverse	
23	SPD_DIR	Speed instruction negation	Valid-Not reverse; Invalid-Reverse	
24	TOQ_DIR	Torque instruction negation	Valid-Not reverse; Invalid-Reverse	

25	PSEC_EN	Internal multi-stage enable	Invalid-Disable internal multi-stage instruction. Valid-Enable internal multi-stage instruction
26	INTP_ULK	Interrupt positioning release	Invalid-No action; Valid-when P08.86 is set to 2 or 4
27	INTP_OFF	Interrupt positioning origin	Can be used as home position signal or deceleration-point position signal
28	HOME_IN	Homing origin point	Valid-Can be used as home position signal or deceleration-point position signal
29	STHOME	Homing start	Start homing
30	ESTOP	Emergency stop	Invalid-No action Valid-Emergency stop
31	STEP	Step enable	Valid-Step enable Invalid-Instruction is 0
32	FORCE_ERR	Forced error protection	Invalid-No action Valid-Forced error protection
33	HOM_DEC	Homing deceleration point	Invalid-No action Valid-Switchover to low-speed search homing
34	INTP_TRIG	Interrupt positioning trigger	Invalid-No action Valid-Valid: when P08.86 is set to non-zero value, can only use Di8 or Di9.
35	INPOSHALT	Internal position commands generation pause	Invalid-Deaccelerate or pause internal multi-stage position and interruption positioning
36	ANALOG_OFF	Analog input prohibition	Invalid-No action; Valid-Prohibit analog input
37	ENC-SEN	SEN enabled absolute position data send	Invalid-No action; Valid-OA0C02 send absolute position data, cannot enable servo at the same time

Value	Sign	Name	DO function description	Remarks
1	S_RDY	Servo ready	Valid-Servo ready Invalid-Servo not ready	
2	S_ERR	Servo error	Valid when detecting error	
3	S_WARN	Servo warning	Valid when warning signal output (disconnected)	
4	TGON	Motor rotation	Valid-When motor speed is larger than settings of P04.43. Invalid-Invalid motor rotation signal	
5	V_ZERO	Motor speed is 0	Valid-Invalid motor speed is non-zero. Invalid-Motor speed is zero.	
6	V_CMP	Speed conformly	Speed control, valid when absolute deviation of motor speed and speed instruction is less than the settings of P04.44.	
7	COIN	Positioning completed	Position control, valid when pulse deviation is less than the settings of P04.47	
8	NEAR	Positioning near	Position control, valid when pulse deviation is less than the settings of P04.50	
9	T_LT	Torque in limit	Valid-Motor torque is in limit Invalid-Motor torque is not in limit	
10	V_LT	Speed in limit	Valid-Motor speed is in limit Invalid-Motor speed is not in limit	
11	BKOFF	Brake release	Valid-Break release Invalid-Break recover	
12	T_ARR	Torque reached	Valid when torque feedback reaches the settings of P04.55, allowable fluctuations ±10µm	
13	V_ARR	Speed reached	Valid when speed feedback reaches the settings of P04.46, allowable fluctuations ±10µm	
15	INTP_DONE	Interrupt positioning complete	Output after interrupt positioning complete	
16	BD_OUT	Dynamic brake output	Externally connecting relay or contactor and current-limiting resistor	
17	HOME	Homing complete	Valid-Home return completed Invalid-Home return not completed	
18	INTP_WORK	Interrupt positioning working	Interrupt positioning working	
19	PCOM1	Position 1 comparator trigger signal	Output trigger signal when position 1 reaches the corresponding range	
20	PCOM2	Position 2 comparator trigger signal	Output trigger signal when position 2 reaches the corresponding range	
21	PCOM3	Position 3 comparator trigger signal	Output trigger signal when position 3 reaches the corresponding range	
22	PCOM4	Position 4 comparator trigger signal	Output trigger signal when position 4 reaches the corresponding range	

### Parameter list

Control modes: P- position control, S- speed control, T- torque control  
 \* means applicable, - means not applicable

7

8

Parameter number	Description	Control mode	P	S	T
00	Motor positive direction definition		*	*	*
01	Control mode selection		*	*	*
02	Real time auto-tuning		*	*	*
03	Stiffness grade setting		*	*	*
04	Load inertia ratio		*	*	*
05	Position instruction source		*	*	*
07	Pulse train form		*	*	*
08	Instruction units per motor one revolution (32-bit)		*	*	*
09	Electronic gear numerator (32-bit)		*	*	*
12	Electronic gear denominator (32-bit)		*	*	*
14	Pulse output counts per motor one revolution (32-bit)		*	*	*
16	Pulse output positive direction definition		*	*	*
17	Pulse output OUT_Z polarity		*	*	*
18	Pulse output function selection		*	*	*
19	Position deviation too large threshold		*	*	*
21	Regenerative resistor setting		*	*	*
22	External regenerative resistor capacity		*	*	*
23	External regenerative resistor resistance value		*	*	*
24	External regenerative resistor heating time constant		*	*	*
25	Regenerative voltage threshold		*	*	*
26	Step value setting		*	*	*
27	High-speed pulse train form		*	*	*
31	Motor type selection		*	*	*
32	DDL motor polar pitch (N-N)		*	*	*
33	DDL scale resolution		*	*	*
34	DDL motor rated current		*	*	*
35	DDL rated thrust		*	*	*
36	DDL maximum thrust theoretical value		*	*	*
37	DDL max. speed		*	*	*
39	DDL rotor mass		*	*	*
40	DDL Stator phase resistance Rs		*	*	*
41	DDL motor Lr (line inductance2)		*	*	*
42	DDL motor Ld (line inductance2)		*	*	*
43	DDL Back EMF Coefficient		*	*	*
44	DDR encoder resolution (32-bit)		*	*	*
47	DDR motor rated current		*	*	*
48	DDR rated torque		*	*	*
49	DDR Maximum torque theoretical value		*	*	*
50	DDR motor max. speed		*	*	*
51	Reserved		*	*	*
52	DDR motor rotor inertia		*	*	*
53	DDR stator resistance Rs		*	*	*
54	DDR motor Lr		*	*	*
55	DDR motor Ld		*	*	*
56	DDR Back EMF Coefficient		*	*	*
57	Reserved		*	*	*
58	Reserved		*	*	*
59	DDT motor response fine-tuning coefficient		*	*	*
60	Magnetic pole seeking method		*	*	*
61	Magnetic pole seeking current		*	*	*
62	Magnetic pole seeking action threshold value		*	*	*
63	Magnetic pole seeking static threshold value		*	*	*
64	DOLD/DR Feedback source		*	*	*
66	DOLD/DR Motor Z- electrical angle		*	*	*

Parameter number	Description	Control mode	P	S	T
00	Position loop gain 1		*	*	*
02	Speed loop integral time 1		*	*	*
03	Speed detection filter 1		*	*	*
04	Position instruction filter 1		*	*	*
05	Position loop gain 2		*	*	*
06	Speed loop gain 2		*	*	*
07	Speed loop integral time 2		*	*	*
08	Speed detection filter 2		*	*	*
09	Torque instruction filter 2		*	*	*
10	Speed regulator PDFF coefficient		*	*	*
11	Speed feedforward control selection		*	*	*
12	Speed feedforward gain		*	*	*
13	Speed feedforward filtering time		*	*	*
14	Torque feedback forward control selection		*	*	*
15	Torque feedforward gain		*	*	*
16	Torque feedforward filtering time		*	*	*
17	Digital input GAIN_SWITCH1 function selection		*	*	*
18	Position control gain switchover delay		*	*	*
20	Position control gain switchover class		*	*	*
21	Position control gain switchover hysteresis		*	*	*
22	Position control gain switchover time		*	*	*
23	Speed control gain switchover mode		*	*	*
24	Speed control gain switchover delay		*	*	*
25	Speed control gain switchover class		*	*	*
26	Speed control gain switchover hysteresis		*	*	*
27	Torque control gain switchover mode		*	*	*
28	Torque control gain switchover delay		*	*	*
29	Torque control gain switchover class		*	*	*
30	Torque control gain switchover hysteresis		*	*	*
31	Observer enabled		*	*	*
32	Observer out of frequency		*	*	*
33	Observer phase compensation time		*	*	*
34	Observer inertia coefficient		*	*	*

Parameter number	Description	Control mode	P	S	T
00	Modbus axis address		*	*	*
01	Modbus baud rate		*	*	*
02	Modbus data format		*	*	*
03	Communication overtime		*	*	*
04	Communication response delay		*	*	*
05-08	Communication DI enabling setting 1-4		*	*	*
09-10	Communication DO enabling setting 1-2		*	*	*
11	Communication instruction holding time		*	*	*
12	AO function or CAN communication enabled		*	*	*
13-15	CAN communication setting 1-3		*	*	*

Parameter number	Description	Control mode	P	S	T
00	External encoder using method		*	*	*
01	External encoder pitch (32-bit)		*	*	*
03	Full-closed excessive hybrid deviation threshold (32-bit)		*	*	*
04	Encoder status		*	*	*
05	Hybrid deviation control setting		*	*	*
06	Hybrid vibration suppression gain		*	*	*
07	Hybrid vibration suppression time constant		*	*	*
09	Unit for full-closed hybrid deviation (32-bit)		*	*	*
11	Unit for internal encoder counting (32-bit)		*	*	*
13	External encoder counting value (32-bit)		*	*	*
16	Position comparison output mode		*	*	*
17	1st position		*	*	*
19	2nd position		*	*	*
21	3rd position		*	*	*
23	4th position		*	*	*
25	Signal effective time 1		*	*	*
26	Signal effective time 2		*	*	*
27	Signal effective time 3				