




— 禾川科技 —



EtherCAT Coupler Communication Manual



Ethercat to CANopen Communication Card Wiring Diagram



(For connections between CAN network nodes, check the CAN Communication section.)


| Pin definition | 1 | 2 | 3 | 4~6 | 7 | 8 |
|----------------|------|------|-----|-----|-----|-----|
| | CANH | CANL | GND | — | +5V | GND |

NOTE: The order of EtherCAT input and output must not be reversed.

Note: The coupler can only be connected to the CN3 port of the VFD.



Interconnection of multiple frequency converters



VFD parameter settings


| Parameter | Value | | Note |
|-----------|-------|---|---|
| P00.02 | 2 | Serial port command communication | |
| P00.03 | 9 | Main frequency source set by communication | |
| P15.00 | 2 | Communication method selection CANopen card | |
| P15.01 | | Node number | EtherCAT axis 1 is CAN node 1, and so on. |
| P15.02 | 495 | Baud rate | Default 500k baud rate |
| P24.13 | 1 | CAN communication protocol | 0-Internal network can; 1-canopen Set 2140 in P24.00 before modifying other parameters in the P24 group. |

Note: A terminal resistor must be inserted into the CN2 terminal of the frequency converter.





Indicator notes

| Name | Function | Status description | Note |
|------|---|--|--|
| PWR | Power indicator | Constant on: Power supply normal; Constant off: Power supply abnormal. | |
| CAN | CAN communication status indicator | 1 Steady off: All slave communications are normal; 2 Steady on: Slave communications are abnormal; 3 Flashing on and off: Slave communications are unstable; | When the light is constantly off, check if error code A16 (communication error) appears on the slave station panel. If A16 appears, verify the drive parameters and check the wiring connection. |
| ECAT | EtherCAT communication status indicator | 1 Steady off: Startup 2 Slow flashing: Safe operation; 3 Fast flashing: Pre-operation 4 Steady on: Normal operation | After starting the EtherCAT master, the status light will flash first and then remain solid. If communication errors occur, check the master configuration and ensure the connection cable is an 8-core cable. |

Network configuration when using EtherCAT to CANopen communication card + Q series PLC




Install the xml file




Create project

1. Create a project;




2. Click “Login” (scanning is possible even when not logged in) and scan the slave devices based on the EtherCAT master.




Create project

3. Re- login after when there is no connection icon(Green circle) shows




Configure process parameters

1. Double-click the EtherCAT slave and select expert setting.



2. Insert input or output parameters (add according to index) in the expert process data.



Configure process parameters

从对象目录中选择条目

显示可以添加的输入数据

| 索引\子索引 | 名称 | 标志 | 类型 | 默认 |
|---------------|--------------|----|------|-----|
| :16#07 | P0006 | RW | UINT | 16# |
| :16#08 | P0007 | RW | UINT | 16# |
| :16#09 | P0008 | RW | UINT | 16# |
| :16#0A | P0009 | RW | UINT | 16# |
| :16#0B | P0010 | RW | UINT | 16# |
| :16#0C | P0011 | RW | UINT | 16# |
| :16#0D | P0012 | RW | UINT | 16# |
| :16#0E | P0013 | RW | UINT | 16# |
| :16#0F | P0014 | RW | UINT | 16# |
| :16#10 | P0015 | RW | UINT | 16# |
| :16#11 | P0016 | RW | UINT | 16# |
| 16#6040:16#00 | Control Word | RW | UINT | 16# |
| 16#60FE:16#00 | DOSTatus | RW | UINT | 16# |
| 16#60FF:16#00 | SetFrq | RW | UINT | 16# |

名称: SetFrq
 索引: 16# 60FF 位长度: 16
 子索引: 0
 数据类型: UINT

确定 取消

D:\桌面\Q工程文件\1\未命名1\未命名1.project - HCP Works3(V1.2.0)

文件 编辑 视图 工程 编译 在线 调试 工具 窗口 帮助

设备

启动参数

变量 映射 通道 地址 类型 单元 描述

| | | | |
|--------------|------|------|-------------|
| Control Word | %QW0 | UINT | Control ... |
| SetFrq | %QW1 | UINT | SetFrq |
| DOSTatus | %QW2 | UINT | DOSTatus |
| Status Word | %IW0 | UINT | Status ... |
| P2821 | %IW1 | UINT | P2821 |


在全局变量中声明在程序中调用即可

```


//{attribute 'qualified_only'}
VAR_GLOBAL
DO状态 AT %QW2: UINT;
控制字 AT %QW0: UINT;
状态字 AT %IW0: UINT;
END_VAR

```

Control DO status



Control DO status




Control DO status


| Correspondence | DO status | |
|----------------|-----------|-------|
| | bit0 | Relay |
| | bit1 | DO1 |
| | bit2 | DO2 |

Set the inverter parameter relay output selection (06.01) and DO output selection (06.02—06.03) to communication control (20).


Beckhoff PLC and VFD EtherCAT communication




Beckhoff PLC and VFD EtherCAT communication



Beckhoff PLC and VFD EtherCAT communication



Beckhoff PLC and VFD EtherCAT communication



| Name | Index | Function | Description | Read/Write |
|--------------|------------|--|--|------------|
| Status Word | 16x6041:00 | Read the operation status of the frequency converter. | 1: Running in forward direction | R |
| | | | 2: Running in reverse direction | |
| | | | 3: Shutdown | |
| | | | 4: Fault | |
| SetFreq | 16x60FF:00 | Modify the running frequency. | -1000%~1000% | W |
| Control Word | 16x6040:00 | Control the operating status of the frequency converter. | 1: Forward rotation | W |
| | | | 2: Reverse rotation | |
| | | | 3: Forward JOG | |
| | | | 4: Reverse JOG | |
| | | | 5: Free stop | |
| | | | 6: Shutdown based on shutdown mode function code | |
| | | | 7: Fault reset | |
| | | | 8: Forward/reverse switching | |
| DOStatus | 16x60FE:00 | Control the DO status. | bit0:Relay status | W |
| | | | bit1:D01 status | |
| | | | bit2:D02 status | |

| Name | Index | Function | Description | Read/Write |
|--------|------------|--|--|------------|
| P00.00 | 16x6000:01 | GP type display | 1: G-type (constant torque load model) 2: P-type (fan, pump load model) | W |
| P00.01 | 16x6000:02 | Motor control mode | 0: 0: Sensorless vector control (SVC) 1: Reserved 2: V/F control | W |
| P00.02 | 16x6000:03 | Command source selection | 0: Control panel control 1: External terminal control 2: Communication control | W |
| P00.03 | 16x6000:04 | Main frequency source X selection | 0: Digital setting (no power memory) 1: Digital setting (power memory) 2: AI1 3: AI2 5: PULSE setting 6: Multi-step command 7: Simple PLC 8: PID 9: Communication setpoint | W |
| P00.04 | 16x6000:05 | Auxiliary frequency source Y selection | 0: Digital setting (no power memory) 1: Digital setting (power memory) 2: AI1 3: AI2 5: PULSE setting 6: Multi-step command 7: Simple PLC 8: PID 9: Communication setpoint | W |
| P00.05 | 16x6000:06 | Frequency source superposition selection | Units Digit: Frequency Command Selection 0: Main frequency source X1: Result of main/auxiliary calculation (relationship determined by tens digit) 2: Switch between main frequency source X and auxiliary frequency source Y 3: Switch between main frequency source X and calculation result 4: Switch between auxiliary frequency source Y and calculation result Tens Digit: Main/Auxiliary Frequency Calculation Mode 0: Main + Auxiliary 1: Main - Auxiliary 2: Maximum value of the two 3: Minimum value of the two | W |

| | | | | |
|--------|------------|---|---|---|
| P00.06 | 16x6000:07 | Auxiliary frequency source Y range selection during superposition | 0: Relative to the maximum frequency 1: Relative to frequency source X | W |
| P00.07 | 16x6000:08 | Auxiliary frequency source Y range during superposition | 0%~150% | W |
| P00.08 | 16x6000:09 | Maximum frequency | 50Hz~599Hz | W |
| P00.09 | 16x6000:0A | Upper limit frequency source | 0: P00.10 setting 1: AI1 2: AI2 4: PULSE pulse setting 5: Communication setting | W |
| P00.10 | 16x6000:0B | Upper limit frequency | Lower limit frequency P00.11 to maximum frequency P00.08 | W |
| P00.11 | 16x6000:0C | Lower limit frequency | 0Hz to upper limit frequency P00.10 | W |
| P00.12 | 16x6000:0D | Preset frequency | 0Hz to maximum frequency P00.08 | w |
| P00.13 | 16x6000:0E | Acceleration time 1 | 0s~6500s | w |
| P00.14 | 16x6000:0F | Deceleration time 1 | 0s~6500s | w |
| P00.15 | 16x6000:10 | Upper limit frequency offset | 0Hz to maximum frequency P00.08 | w |

| Code | Name |
|--------|----------------------------------|
| P28.00 | Current power-on time |
| P28.01 | Current operating time |
| P28.02 | Inverter operating status |
| P28.03 | Fault information |
| P28.04 | Operating frequency |
| P28.05 | Set frequency |
| P28.06 | Bus voltage |
| P28.07 | Output voltage |
| P28.08 | Output current |
| P28.09 | Output power |
| P28.10 | Target torque |
| P28.11 | Output torque |
| P28.12 | Feedback frequency |
| P28.13 | Detection frequency |
| P28.14 | Resolver position |
| P28.15 | ABZ position |
| P28.16 | Z signal counter |
| P28.17 | Synchronous motor rotor position |
| P28.18 | Power factor angle |
| P28.19 | Controller temperature |
| P28.20 | Motor temperature value |
| P28.21 | DI input status |
| P28.22 | DO output status |